

# Installation Instructions

## 600A INSULATED PARKING BUSHING

### P625IPB/P635IPB

Kit contents may include:

- \* Insulated Parking Bushing (P625IPB/P635IPB)
- \* Silicone Lubricant (P6SL1)

- \* Installation Instruction Sheet

The P625IPB/P635IPB connector is rated 600 Amperes and 25 kV or 35 kV respectively.

#### Warning

- \* System must be de-energized during installation or future operations on this product or its components.
- \* Do not touch or move energized connectors or components by hand.
- \* Excess distortion of the assembled connector may result in its failure.
- \* Failure to follow these instructions will result in damage to the connector and serious or fatal injury.


Check contents to be sure they are:

- \* correct
- \* complete

- \* undamaged
- \* properly fitted with cable and mating components


#### STEP 1 – CLEAN AND LUBRICATE

1. Remove protective shipping cap from bushing interface.
2. Clean and lubricate interface with lubricant supplied or approved equivalent.



#### STEP 2 – INSTALL INSULATED PARKING BUSHING

1. Grasp eyebolt with hotstick.
2. Lower insulated parking bushing into parking stand.
3. Turn eyebolt clockwise until insulated parking bushing is securely fastened.



#### STEP 3 – ASSEMBLE

1. Disconnect deadbreak connector from de-energized apparatus bushing.
2. Use hotstick to position deadbreak connector onto insulated parking bushing.
3. Turn deadbreak connector bolt clockwise into insulated parking bushing until tightly sealed.
4. Cover de-energized apparatus bushing with a 600A insulated protective cap.
5. When not use, cover Insulated parking bushing interface with Insulated protective cap or shipping cap to keep interface clean.

